




“B” Pan Sizing Chart for Model 75B and model 75LB

Duct Opening Order	Overall Height	Duct Opening Order	Overall Height
4	5	29	33
5	6	30	34
6	7	31	35
7	8	32	36
8	10	33	37
9	11	34	38
10	12	35	39
11	13	36	41
12	14	37	42
13	15	38	43
14	16	39	44
15	17	40	45
16	18	41	46
17	20	42	47
18	21	43	48
19	22	44	49
20	23	45	51
21	24	46	52
22	25	47	53
23	26	48	54
24	27	49	55
25	28	50	56
26	29	51	57
27	31	52	58
28	32	53	59



231 Commerce Dr. Montgomeryville, PA 18936
Tel: 215-412-4445 Fax: 215-412-4409
Email: lloydind@firedamper.com

138 Industrial Loop West, Orange Park, FL 32073
Tel: 904-541-1655 Fax: 904-541-1657
Email: lloydind1@bellsouth.net

B1, 4/F., Luen Ming Hing Factory Building
36 Mok Cheong St.,
To Kwa Wan, Kowloon, H. K.
Tel: 852-2760-4188 Fax: 852-2760-4177
Email: tatanlexyim@lloydasia.com

